


Installation Instructions for ecom USB driver

The USB driver works on computers with operating systems Windows 2000, Windows XP, Windows Vista, Windows 7 and Windows 10.

Hereto a free USB 1 or USB 2 Pc connection is necessary.

BEFORE connecting the USB RS232 adapter cable with the PC for the first time, the installation programme, to be found on the driver CD, must be executed.



Wählen Sie **Install** und folgen Sie den weiteren Anweisungen. Eventuell muss nach Abschluss der USB-Treiberinstallation der Computer neu gestartet werden (abhängig vom eingesetzten Betriebssystem).

The access to the device occurs via a virtual COM interface. The number of the virtual COM interface is depending on the hardware equipment of the computer and is allocated by the operating system.

The allocated number can be checked via the device manager of the computer.

In the following example **COM3** has been selected by the operating system as interface:



Then the ecom instrument can then communicate with the PC via **COM3**.